


ワイヤレススピーカー/FMレシーバ
ユーザーマニュアル

Poisonスピーカー本体 x1
充電用USBケーブル x1
ユーザーマニュアル(本書)

仕 仕様

本体大きさ: 184 x 105 x 70mm
 スピーカーサイズ: 52mm(直径) x 2
 スピーカー定格出力: 10Wx2
 音楽再生時間: 最大約6時間(内蔵リチウムイオン電池フル充電時)
 充電時間: 約4~6時間
 FMラジオ放送周波数帯域: 76~108MHz
 Bluetooth到達距離: 最大10メートル(直線見通し距離)
 サポート規格: Ver. 4.2
 Bluetooth名: Poison M @ LOFREE

各 各部機能、概要



- [illegible]

使用 使用方

[illegible]

オートチャンネルスキャン
回転ダイヤルを3秒以上押し続けると、緑色のLEDが点滅し、スキャンを開始します。スキャン中はFM周波数インジケータ上のLEDが右から左に移動し、確定すると、そのチャンネルを保持し、緑色のLEDは点灯し続けます。次のチャンネルを選択する場合は、もう一度回転ダイヤルを押します。回転ダイヤルを再度3秒押すと、保持されている現在のチャンネルをクリアし、再度スキャンを始めます。

6. 音量調整の方法
ボリュームアップ、ダウンボタンを何回か、又は押し続けることで音量の調節ができます。

付属のmicro USBケーブルを、カメラと接続し、充電します。

バッテリー残量が10%以下になると、バッテリーインジケータが赤く点滅を始める。充電中インジケータは赤く点灯し、完全に充電されると消灯します。充電が完了すると、残量が10%を切るまでは、バッテリーインジケータは消灯状態を継続します。

Q Q&A

- [illegible]

警告
・本製品を使用
するときは、

・機器の分解、改良はしないでください。火災、感電の原因になります。

・発煙、異臭や異音が生じた場合は、直ちに使用を中止してください。また、その他製品に異常がある場合は、ご利用を直ちに中止し、速やかに弊社ユーザサポート係までご連絡ください。

・本体を濡らしたり、水気のある場所で使用したりしないでください。感電や火災、本製品の故障の原因となります。

・本製品を分解
本製品は、

[illegible]

POISON M
EP203 Wireless Speaker


In The Box

Poison Speaker x 1
3.5mm Auxiliary Cable x 1
USB Charging Cable x 1
User Manual x 1

Spec:

Product Size : 184 x 105 x 70mm
Bluetooth Distance : 10 meters (open area)
Bluetooth Version : 4.2
Speaker Size : 52mm x 2
Rated Power : 10W x 2
Music Playtime : Up to 6 hours
FM radio broadcasting frequency : 88~108MHz
Charging Time : 4~6 hours
Battery : Built-in lithium battery
Bluetooth Name : Poison M80
Bluetooth Model : M80FREE

 Overview



- On/Off Button
 - Long press 3 seconds to turn on/off
 - Short press to switch modes among Bluetooth, FM and Line-in
- Play/Pause Button
 - Press once to play/pause
 - Long press 3 seconds to disconnect Bluetooth
- Vol+
 - Long press 3 seconds to auto channel scanning
- Vol-
 - Press once for auto channel change
 - Press for manual channel scanning
- Rotating Dial
 - Long press 3 seconds for auto channel scanning
- LED Indicator
 - Blue LED blinks, Bluetooth pairing
 - Blue LED remains bright after pairing successfully, Bluetooth paired
 - Blue LED remains bright, FM mode
 - White LED blinks, No line-in connected
 - White LED remains bright, Line-in connected
- Battery Indicator
 - FM Screen
- Audio Jack
- Charging Port

F Function Description

- [illegible]

F40

- Can you use the **Person** if my **Model** or **TV** doesn't have Bluetooth?
You may use the **3.5mm** cable instead of cable (aka aux cable) included in the box to connect the **Person** to your **Model** or **TV** if Bluetooth were on the market.
- Does it work as a **speakerphone**?
No.
- How can I connect the **Person** with **HDTV**?
You may use the **3.5mm** cable connected with your brother's **HDTV**. otherwise, there is no way to connect the **Person** with **HDTV** if you don't have Bluetooth. Think you may use Bluetooth receiver for your **TV**. I have a link to know how to connect the **Person** to **HD** receiver. <http://www.hugoboss.com/en-us/attach-Bluetooth-headphones-to-your-TV>
- I can't find the **Person** on my **PC**.
1. Make sure the **Person** is in **Bluetooth** technology, please make sure,
2. If the **Person** is not resting on an metal surface,
3. If the **Person** is not connected with the **Person** Bluetooth connection or turn on
4. Avoid to keep the **Person** far away from your connected device which may also be the reason for not connecting the **Person** with your **PC**.
5. Make sure the **Person** is fully charged. Press and hold the power on/off button (aka "Power On" Bluetooth mode) and scan again on your **PC**.
- I need a passport for Bluetooth pairing.
No. There are no passport for Bluetooth pairing. It is just a Bluetooth connection problem and some mobile phone may happen like this.
- How successfully I connected my **Person** with my phone, but it failed later.
No. There are many reasons for this. I will try to help you. Just follow the problem for Bluetooth my connection with my phone.
- As Bluetooth is a wireless transmission technology, please avoid putting the **Person** near the **Person** or other electronic devices to avoid interference.
- What language does the **Person** support?
It only supports English.
- Can I use the **Person** with USB?
The **Person** uses Micro USB (Type C) charging.
It supports Micro USB.
- Can I connect my **Person** to USB cable.
The USB cable port is for charging purpose. Please connect with the **3.5mm** aux cable to connect my **Person** to USB cable.
- Can I turn on with auto wake when power is off?
No.
- Can I turn in music mode to audio mode?
Make sure the **Person** is in **Line-in** mode, please try to power off and make sure the **Person** is in **Line-in** mode. If it is not done with, you may try to connect with another device, thanks.
- How long does the **Person** last for a single charge?
The **Person** has a battery life of 10 hours. The **Person** has a wireless music streaming with volume level in 80~85%, however, music playtime of lists and apps are approximately 10 hours.
- The **Person** is not charging.
1. Make sure the **Person** is fully charged.
2. Charge with power lower than 5V/2A, it is safe to charge 5V/2A, if you use an adapter with power lower than 5V/2A, it is safe to charge 5V/2A.
3. Please check if the indicator light is on when the power connected.
4. Please make sure the **Person** is fully charged when the power connected.
5. The charging indicator remains red while charging, it goes off once fully charged.
- Can I listen to music with my phone?
Yes, but it will be a little noisy.
- Can I scan signal with/less radio channel / signal not clear under FM mode.
DTF signal will be affected if there is strong magnetic or other high current in the area.
- Can I use speaker to make the speaker to another position such as living room?
No.

Shenzhen Lofree Culture Co., Ltd.
http://lofree.co
Address: F8, F518 Idea Land, Bao Yuan Rd, Bao'an District, Shenzhen, China
Designed by Shawn@lofree
Assembled in China

[f @lofree.co](#) [x @lofree.co](#) [t @lofreeco](#)